

# Little Magical Conch

## Service-650

### Twin-tub Washing Machine

# Haier



- Please read this manual carefully before using.
- Please retain it for future reference.

## Contents

### Before using

Names of the parts.....the 2nd cover	
Safety precautions .....	1
Installation and adjustment .....	3
Introduction of the major functions .....	5

### Using process

Preparation before washing .....	6
The musts in washing .....	7
Usage of the detergent .....	8
Washing sequence .....	9
Disposal after washing .....	13

### Trouble-shooting\*

Answers to question.....	15
--------------------------	----

Packing list .....	17
--------------------	----

Specification.....the back cover	
----------------------------------	--

# Names of the parts

## Before Using

Honorable users,


Thanks for your choosing Haier products.

Haier products integrate high-tech, precision frontier science and possess the best quality among similar products. To facilitate your operation, please read the manual carefully and operate this machine according to it.




Haier's star-level service is always accompanying you. No matter what problems you meet in use please do not hesitate to contact us by the telephone number and address on the certificate of warranty. We are at your service all the time.

Thanks again for your choosing and introducing Haier products.



Haier-sincere forever!



### Accessories

	Water-filling jointer (one piece)
	Water inlet hose (one piece)
	Gland (one piece)


### Meaning and description of the symbols

Warning sign 	Contents marked with that symbol are related to the safety of the product and the personal safety of the users. Please operate in strict conformity to the contents, otherwise it may cause damage of the machine or injure the personal safety of the user.
Forbidding sign 	Contents marked with that symbol are actions forbidden to perform. Performing of those actions may result in damage of the machine or injure the personal safety of the user.


# Safety precautions

## Before Using

Be sure to use three-phase receptacle. Earth the earthing terminal of the receptacle reliably.




Be sure to pull the plug off when there's power failure, or the machine is being moved, cleaned or when it is idle.



If the power cord is bad, to avoid risk it is required to replace it by the technicians of our special shop or the after-sale service department. Keep the pin of the power plug clean.




In case the washing machine is installed on ground with carpet, do not block the ventilation hole with carpet.




Ventilation hole at the bottom of the washing machine



Do not use water hotter than 50°C .




Do not put the machine at damp place like the bathroom . Never wash it with water.



Do not wash water-proof laundries such as the raincoat, bicycle shelter etc. To avoid abnormal vibration during spinning.




Do not share one receptacle with other electric appliances. Do not use it in case that the power plug is damaged or the inserting into the receptacle is loose.




# Safety precautions

## *Before Using*

Do not stretch hands into the working machine. It is dangerous even if the rotation is slow. Take special care of the children.



Do not decompose, repair or alter the machine by yourself.




Do not put any hot or heavy items (such as the kettle with hot water) on the washing machine.




Do not wash laundries with volatile materials (such as thinner, petrol etc.).



Handicapped or children without care shall not use the machine.



Keep the machine away from direct sunlight and heat source like the heater.




Please install and adjust the machine according to the requirement of the manual. It is very important to your security and correct operating the machine.


### Usage of the drain hose

The drainage shall be smooth with the drain hose.

1. The height of the drain hose shall be less than 10cm, or the drainage will not be smooth enough and cause incomplete drainage.




2. Do not tramp or press the drain hose.




3. If the drain hose is too long, cut it at mid point. To make smooth drainage, cut the front end of the hose slantingly.



4. If extra drain hose is needed, please make separate purchase. The inner diameter of the extra hose shall not less than 30mm, and the length shall not exceed 1.5m.



If the extra hose is too long, cut it either at point A or B.



## How to change the direction of the drain hoses

- Figure 1 indicates the ex factory installation position of the drain hose.

### Extend the drain hose from the side of spin tub

- Put soft items on the ground. Lean the machine down gently with the front surface facing the ground. Take off the drain hose from the cabinet. Take the hose out of the fixing groove. (See to Figure 2).




Figure 1

- Embed the drain hose into the groove along the side of the spin tub in the order of (1)~(3), heading for the side of the spin tub. (See to Figure 3).




Figure 2

- Embed the drain hose into the groove with hands. Take care not to damage the drain hose in fastening the fixing clamp.




Figure 3

### Extend the drain hose from the rear side

- Take out the drain hose from the fixing groove. Extend it from the rear side as per the direction of the arrow. (When the drain hose is extended from the rear side, it can be hung on the point for drain hose at the two sides of the cabinet.) (See to Figure 4).






Figure 4

## Install the water inlet hose; Select the water level

Insert the water inlet hose into the water-filling entrance on the control panel, then push the water-filling jointer into the entrance on the control panel. (To dismantle the water inlet pipe, just push the control handle as indicated in the figure and pull it out)

Select water level according to the quantity of the laundries.

- Set the water level adjusting lever to needed line.



# Introduction of the major function *Using process*

The machine has good comprehensive performance, and nice appearance.

For the design on mute ,It adopts complete enclosed base frame and low-noise motor, and thus reduces the working noise significantly. We can guarantee that the purchase of this machine will bring you a clean world without disturbing your quiet life.


## Cascade washing

The cascade washing it adopts can enhance the strength of the water current, and dissolve the detergent quickly and completely. At the same time it can produce flushing effect, and improve the washing effect.



## Foam-removing spinning during high-efficiency rinsing

Use the foam-removing spinning to remove the extra detergent liquid. It can both shorten the washing time and save the water consumption.




The effect is best when the laundries quantity is below 80% of the rated value.

## Quick water-filling entrance

If you do not need spraying spin, you can fill water into the wash tub directly through this entrance. It can reduce the humidity inside the control panel significantly and prolong the operating life of the components.

Quick water-filling entrance



# Preparation before washing

## Using process







### Preparation before washing

1. Connect the water inlet hose.
2. Confirm that the washing machine is earthed reliably. Then insert the power plug into the receptacle. Do not connect the earth terminal to the gas pipe and tap water pipe.
3. Put down the drain hose.



4. Slanting or uneven ground may result in unstable working or abnormal noise. Please make the machine stand horizontally.

Pay attention to followings before washing the laundries

Confirm if there's special requirement for the laundries.	Clear the pocket. Take out the coins, sand, hairpins etc.	Fasten the buttons and zippers.	The quantity of the laundries shall not exceed the rated value. The big laundries like the jeans shall be put in loosely.	When the pulsator is running, the buttons of the laundries may cause noise. For the sake of discretion, please put the laundries with buttons into other laundries.
				




# The musts in washing

## Using process



- The capacity of washing and spinning of the machine refer to the largest weight of the standard laundries under dry condition that can be washed or spinned in one time. Laundries quantity in one washing cycle shall be lower than the rated capacity. The largest capacity of this machine is 5.0 kg.
- The thickness, size, type of the cloth will influence the actual washing capacity. It is suitable to put in reasonable amount of laundries and the laundries can be turned round in washing for one time washing.
- Do not select "High" water level for laundries less than 2.4kg, so as to avoid splashing of water.

### Reference weight of the laundries



# Usage of the detergent *Using process*

## How to use the whitener

- Fill water to decided level. Dilute the whitener with container. Pour it slowly into the washing tub.
- Avoid using whitener on laundries with color or pattern as they are prone to lose color.
- The whitener shall not touch the laundries directly.
- Refer to the user's manual for the usage and quantity of the whitener.
- For powder whitener, please dissolve it before using.

## How to use the washing powder

- |   |  |
|---|--|
| <ul style="list-style-type: none"> <li>● Direct dissolved in the machine:                     <ol style="list-style-type: none"> <li>1.Fill small quantity of water.</li> <li>2.Add the powder . Run for 30 seconds to dissolve it completely.</li> <li>3.Put it in the laundries. Select suitable water level.</li> </ol> </li> <li>● The instant dissolving of the washing powder:                     <ol style="list-style-type: none"> <li>1.Prepare warm water of 30°C and a container.</li> <li>2.Add the powder while stirring to fully dissolve it.</li> </ol> </li> </ul> | <ul style="list-style-type: none"> <li>● The powder is more prone to pollute the laundries than the detergent. Therefore please use it with proper quantity.</li> <li>● It is suggested not to use high sudsing detergent.</li> <li>● Dosage of different washing powder is different. Please refer to the instruction of the washing powder for the detail dosage.</li> </ul> |
|---|--|

## Selection of the quantity of the washing powder

list 1

Laundries quantity	Water level (Water quantity)	Standard dosage	
		Concentrated washing powder	Common washing powder
3.6kg~5.0kg	High (about43L)	About 36g	About 43g
2.0kg~3.6kg	Medium (about36L)	About 30g	About 36g
Below2.0kg	Low (about30L)	About 25g	About 30g


## Selection of the current , water level and washing time

list 2

Laundries quantity	Current	Water level (Water quantity)	Laundries	Washing time (minutes)
2.4kg~5.0kg	Strong	Medium (about36L) ~ High (about43L)	Knitwear	About3~6
			Cotton,blending,linen	About8~10
			Very dirty and thick	About10~13
			Bed sheet	About7~13
Below2.4kg	Standard	Low (about30L) ~ Medium (about36L)	Silk(thin laundries)	About2~4
			Chemical fiber	About3~6
			Cotton,blending,linen	About8~10

# Washing sequence

## Using process



## Wash

### 1. Water-filling selector

(1) Set the water-filling selector at the "WASH" side.  
(Figure 1)

(2) Set the water level adjusting lever to needed line.

### 2. Fill the water and add the dissolved washing powder to make the water level reach the preset position. (Figure 2)

Run washing program for some time to stir and dissolve the powder completely.

Page 8

### 3. Put in the laundries. If the water quantity is insufficient, please add water.

Page 8

### 4. Select the current.

Select the strength of the current according to the laundries. (Figure 3)

Page 8

### 5. Select the washing time

Select the washing time according to the laundries.  
(Figure 4)

Page 8

### 6. After washing, the buzzer will ring. Set the "WASH SELECTOR" at "DRAIN". (Figure 5).



Figure 1




Figure 2




Figure 3




Figure 4




Figure 5


## Midway spinning

1. Put the laundries into the spin tub evenly and smoothly.

2. Spin:


(1) Put the gland in properly.

- Please put in the gland properly even if the laundries quantity is small.



(2) Close the inner and outer cover of the spin tub.

(3) Spin for 1-2 minutes.




3. Run the foam-removing spinning.

(1) Open the outer cover of the spin tub.

(2) Set the water-filling selector control rod at the "SPIN" side. Fill water for about 1 minute.

- If the water quantity filled is too large, the water may flow out from the wash tub side. Please twist the water tap to limit the water filling.

(3) Close the outer cover of the spin tub.  
Spin for 1-2 minutes.



## Rinsing


### Rinse with water-filing

1. Put the laundries into the wash tub. Select suitable current according to the laundries.



2. Adjust the water level  
Set the water level with water level adjusting lever according to the laundries quantity. Then fill suitable water continuously.

3. Rinse  
Adjust the wash timer to 5-7 minutes to do rinsing.



If the water flows out of the overflow holes, that is overfilling

### Rinse with stored water

(Repeat the midway spinning and rinsing with stored water for 2-3 times)

1. Put the laundries into the wash tub. Select suitable current according to the laundries.



2. Fill water to preset water level.

3. Rinse  
Adjust the wash timer to 2-3 minutes to do rinsing.

- When the laundries quantity is below 2.4kg, please use "Standard" current. If you use "Strong" current, it may splash.

## Spinning

1. Put the laundries into the spin tub evenly and smoothly.
2. Press the gland in the tub properly. Close the inner and outer cover of the spin tub.
3. Spin  
Select suitable spin time according to the laundries, and do spinning.

During spinning, if there's abnormal sound, it is generally owing to slanting placement of the laundries. Please stop the machine and re-order the laundries.

- In spinning, it will pause the work if you open the outer cover of the spin tub. Close it to resume the spinning.

Selection of the spin time list 3

Laundries	Spin time (minutes)
Bed sheet or blanket	About 4~5
Underwear (knitwear)	About 2~4
Swear (chemical fiber)	About 1~2
Blending thin laundries	Within 1 minute



To do spinning and draining or rinsing with water-filling together, please first do spinning for around 1 minute, then do draining or rinsing with water-filling. Otherwise the spinning will stop owing to too much water stored in the spin tub.

# Disposal after washing

## Using process

- After using, please clean the lint and foreign materials of the lint filter and overflow filter in time. Otherwise it may influence your using the machine.
- Please first pull off the power plug from the receptacle before cleaning.

### Cleaning the lint filter

- The lint filter must be used during washing.
- It must be cleaned in time after each using.

1. Take off the lint filter  
Put hand at the indicated position.  
Push down to take it off. ( See to Figure 1)




Figure 1

2. Clean the lint  
Put it in water and clean while it is still wet.(See to Figure 2)




Figure 2

3. Install the lint filter  
After cleaning, insert the bottom of the lint filter ( marked with "down side") into the overflow filter , then push the upper part of the filter in ( marked with " up side ").  
(See to Figure 3)




Figure 3

### Cleaning the overflow filter

- Too much lint on the overflow filter will influence the normal usage of the machine. Please clean it every two months.

- 1、 Take off the overflow filter.  
As indicated in the figure, nip the elastic fixing claw and pull it to the direction of the arrow to take it off.



## Cleaning the overflow filter

2. Take off the corrugation pipe.  
Dismantle the upper part of the corrugation pipe inside the overflow filter (as indicated in Figure 1).




Figure 1

3. Cleaning the overflow filter  
Clean the lint around the filter and flush with tap water.

4. Install the overflow filter.
  - (1).Install the corrugation pipe.
  - (2).Insert the mounting plate at the bottom of the filter into the valve cover.
  - (3).Hang up the hook at the left upper side.
  - (4).Push the upper part in as indicated in Figure 2.




Figure 2

## Disposal of the complete unit

- Wipe the complete unit with soft cloth twisted dry.
- Wipe with neutral detergent if too dirty
- Do not wash it directly by water



- After washing, dismantle the water inlet hose.
- Do not store water in the tub for long period. Discharge the water immediately after each using.
- Pull off the power plug and hang up the power cord.
- Hang up the drain hose.
- Wipe off the water drops on the surface and inside the tub with clean soft cloth. Open the cover of the wash tub and the inner/outer cover of the spin tub for some time (about one hour), then close them.



# Trouble-shooting Answer to question

## If the laundries fall to the outer side of the spin tub


If the laundries fall to the outer side of the spin tub, please take them out immediately.

### 1.Dismantle

As indicated in the figure, push the point marked with "※" to pull the spin tub frame to oblique upwards to dismantle it.


### 2.Install

After install the back edge of the spin tub frame to proper position, push the four points marked with "※" by force to reset it.



Please check carefully. The laundries may fall to the lower part of the outer side of the spin tub (as indicated in the figure).

- If the laundries fall to the outer side of the spin tub, during spinning the draining will get blocked and the rotation speed of the spin tub is reduced.)




## When the remained water is frozen

Prevent the freezing (be sure to discharge the water completely after using)

- After complete draining, set the "WASH SELECTOR" at "STRONG" or "STANDARD". If it is set at "DRAIN", it will be rather difficult for the frozen water to melt.

### When the water is frozen

- Pour hot water below 50℃ into the wash tub to soak it completely. Then turn the pulsator with hands gently. Please confirm the drainage can work normally before next using.



# Trouble-shooting Answer to question

(If there's breakdown, please pull off the power plug before checking) The following phenomena are not breakdowns sometimes. Please confirm again before sending it to repair. If there are real breakdowns, please come to the special maintenance department or after-sale service department of our company. Do not repair it by yourself.

Phenomena	The reason
The machine does not act.	<ul style="list-style-type: none"><li>• Is there power failure?</li><li>• Is the power plug loose?</li><li>• Is the pulsator twisted by foreign materials?</li></ul>
The draining does not work	<ul style="list-style-type: none"><li>• Is the drain hose put down?</li><li>• Is the drain hose frozen?</li><li>• Is the drain hose blocked by foreign material?</li><li>• Are there laundries falling to the outer side of the spin tub?</li></ul>
There's abnormal sound during washing	<ul style="list-style-type: none"><li>• Are there hair pin, coins or metal items brought inside the tub?</li></ul>
There's abnormal sound and violent vibration during spinning	<ul style="list-style-type: none"><li>• Is the machine slanting?</li><li>• Is the gland pressed evenly?</li><li>• Are there laundries falling to the outer side of the spin tub?</li><li>• Are the laundries in spin tub too much?</li></ul>
There may be some water flowing out of the drain hose in the first use of the machine.	<ul style="list-style-type: none"><li>• It is the water remained in the factory inspection of performance.</li></ul>

# Packing list

● User's manual	● One
● Water inlet hose	● One
● Water-filling jointer	● One
● Gland	● One
● Twin-tub washing machine	● One

# Specification

Type	Twin-tub washing machine
Model	XPB50-22S
Power source	Rated voltage 220V~,Rated frequency 50Hz
Water level / Water quantity (about)	High/43L Medium/36L Low/30L
Rated washing capacity (kg)	5.0
Rated spinning capacity (kg)	5.0
Rated input power (W)	Wash 380 Spin 150
Dimension(mm)	L780 W428 H890
Wash pattern	New current + cascade
Weight (kg)	27
Injection pressure	0.02MPa~0.2MPa